## Notes for Figure 6H-28—Typical Application 28 Sidewalk Detour or Diversion

### Standard:


1. When crosswalks or other pedestrian facilities are closed or relocated, temporary facilities shall be detectable and shall include accessibility features consistent with the features present in the existing pedestrian facility.

Guidance:

- 2. Where high speeds are anticipated, a temporary traffic barrier and, if necessary, a crash cushion should be used to separate the temporary sidewalks from vehicular traffic.
- 3. Audible information devices should be considered where midblock closings and changed crosswalk areas cause inadequate communication to be provided to pedestrians who have visual disabilities.

Option:

- 4. Street lighting may be considered.
- 5. Only the TTC devices related to pedestrians are shown. Other devices, such as lane closure signing or ROAD NARROWS signs, may be used to control vehicular traffic.
- 6. For nighttime closures, Type A Flashing warning lights may be used on barricades that support signs and close sidewalks.
- 7. Type C Steady-Burn or Type D 360-degree Steady-Burn warning lights may be used on channelizing devices separating the temporary sidewalks from vehicular traffic flow.
- 8. Signs, such as KEEP RIGHT (LEFT), may be placed along a temporary sidewalk to guide or direct pedestrians.



### Figure 6H-28. Sidewalk Detour or Diversion (TA-28)

**Typical Application 28** 

Note: See Tables 6H-2 and 6H-3 for the meaning of the symbols and/or letter codes used in this figure.

#### Shadow vehicle Arrow board Arrow board support or trailer Sign (shown facing left) 0 (shown facing down) Changeable message sign or support trailer Surveyor Channelizing device Temporary barrier Crash cushion Temporary barrier with warning light Direction of temporary traffic detour Traffic or pedestrian signal Direction of traffic Truck-mounted attenuator Flagger Type 3 barricade High-level warning device (Flag tree) Warning light Longitudinal channelizing device Work space Luminaire Pavement markings that should be $\mathcal{N}\mathcal{N}$ Work vehicle removed for a long-term project

# Table 6H-2. Meaning of Symbols on Typical Application Diagrams

# Table 6H-3. Meaning of Letter Codes on Typical Application Diagrams

Road Type	Distance Between Signs**		
	Α	В	С
Urban (low speed)*	100 feet	100 feet	100 feet
Urban (high speed)*	350 feet	350 feet	350 feet
Rural	500 feet	500 feet	500 feet
Expressway / Freeway	1,000 feet	1,500 feet	2,640 feet

\* Speed category to be determined by highway agency

\*\* The column headings A, B, and C are the dimensions shown in Figures 6H-1 through 6H-46. The A dimension is the distance from the transition or point of restriction to the first sign. The B dimension is the distance between the first and second signs. The C dimension is the distance between the second and third signs. (The "first sign" is the sign in a three-sign series that is closest to the TTC zone. The "third sign" is the sign that is furthest upstream from the TTC zone.)

### Table 6H-4. Formulas for Determining Taper Length

Speed (S)	Taper Length (L) in feet	
40 mph or less	$L = \frac{WS^2}{60}$	
45 mph or more	L = WS	

Where: L = taper length in feet

W = width of offset in feet

S = posted speed limit, or off-peak 85th-percentile speed prior to work starting, or the anticipated operating speed in mph